
# **Quick Installation Guide**

### Printer overview




Note: The interface picture in the quick start guide is for reference only. Please refer to the product specification for the interfaces availability.


# **Printer Installation**


1. Arrange this printer on a reliable flat surface and make sure the power switch is off.

2. Connect the printer to a computer mainframe with a USB cable  $_{\circ}$ 



## Loading the label






#### (2)Pause the printing job

When the printer is printing, press the button to pause a print job. When the printer is paused the LED will blink blue. Press the button again to continue the printing job.


### **Diagnostic tool**



(3) The detail functions in the Printer Function Group are listed as below.

	Function	Description
Calibrate Sensor	Calibrate Sensor	Calibrate the sensor specified in the printer setup group media sensor field
Ethernet Setup	Ethernet Setup	Setup the IP address, subnet mask, gateway for the on board Ethernet
RTC Setup	RTC Time	Synchronize printer Real Time Clock with PC
Factory Default	Factory Default	Initialize the printer and restore the setting to factory defaul
Reset Printer	Reset Printer	Reboot printer
Print Test Page	Print Test Page	Print a test page
Configuration Page	Configuration Page	Print printer configuration
Dump Text	Dump Text	To activate the printer dump mode
Ignore AUTO.BAS	Ignore AUTO.BAS	Ignore the downloaed AUTO. BAS program
Password Setup	Password Setup	Set Diag Tool password
Exit Line Mode	Exit Line Mode	Leave Line mode

### Sensor Calibrate



#### Note:

\* For more information and features about this printer, please refer to the User's Manual inside the CD disk.

\* Specifications, accessories, parts and programs are subject to the change without notice.